



EMBRAGUES CONJUGADAS DE DISCOS DE FRICCIÓN
SERIES 2000 / 2500 / 5000
SERIES 004 / 005 / 006 / 007 / 008
SERIES W 2000 / W 4000

SERIE 2.000

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8	9	
EA 205-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	EA 205-15	70
EA 210-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-09	EA 205-15	70
EA 211-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-10	EA 205-15	70
EA 212-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	EA 205-15	30
EA 213-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	EA 205-15	18
EA 214-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-28	EA 205-15	70
EA 215-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-35	EA 205-15	70
EA 219-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-09	EA 205-15	16
EA 220-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-37	EA 205-15	18
EA 221-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-35	EA 205-15	55
EA 222-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-35	EA 205-15	40

SERIE 2.500

Código del	Código de los Componentes	Par (kgf)
-------------------	----------------------------------	------------------

Embrague	1	2	3	4	5	6	7	8	9	Par (kgf)
EA 250-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	EA 205-15	90
EA 251-00	EA 205-07	EA 205-02	EA 205-01	EA 205-21	EA 205-11	EA 205-20	EA 205-18	EA 205-22	EA 205-15	90
EA 252-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-29	EA 205-15	90
EA 254-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-14	EA 205-15	90
EA 255-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-35	EA 205-15	90
EA 257-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-36	EA 205-15	90
EA 258-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-10	EA 205-15	90
EA 259-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-35	EA 205-15	55
EA 260-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-10	EA 205-15	70
EA 261-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-35	EA 205-15	35
EA 262-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-39	EA 205-15	90
EA 263-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	EA 205-15	30
EA 264-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-40	EA 205-15	90
EA 265-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-41	EA 205-15	90
EA 266-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-30	EA 205-15	90

SERIE 5.000

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8	9	
EA 510-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-14	EA 205-15	90
EA 511-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	EA 205-15	90
EA 515-00	EA 205-07	EA 205-02	EA 205-01	EA 205-21	EA 205-11	EA 205-20	EA 205-18	EA 205-17	EA 205-15	90
EA 516-00	EA 205-07	EA 205-02	EA 205-01	EA 205-21	EA 205-11	EA 205-20	EA 205-18	EA 205-22	EA 205-15	90
EA 517-00	EA 205-07	EA 205-02	EA 205-01	EA 205-21	EA 205-11	EA 205-20	EA 205-18	EA 205-24	EA 205-15	90
EA 520-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-20	EA 205-18	EA 205-36	EA 205-15	90

SERIE 004

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8	9	
004182	004182FD	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	70
004230	004182FD	EA205-35D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	70
004311	004182FD	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	065.985-0	031.105-2	066.999-5	40
004325	004182FD	EA205-41D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	70
004239	EA205-05D	EA205-35D	073.520-7	019.308-0	EA205-03	056.689-7	065.985-0	031.105-2	066.999-5	55

SERIE 005

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8		
005182	005182FD	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	70
005183	005182FD	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	90
005240	005182FD	EA205-10D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	70

SERIE 006

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8		
006182	EA250-05D	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	70
006183	EA250-05D	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	90
006236	EA250-05D	EA505-14D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	90
006312	EA250-05D	EA205-35D	073.520-7	019.308-0	EA205-03	056.689-7	065.985-0	031.105-2	066.999-5	35
006332	EA250-05D	EA205-29D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	90

006338	EA250-05D	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	065.985-0	031.105-2	066.999-5	40
--------	-----------	-----------	-----------	-----------	----------	-----------	-----------	-----------	-----------	----

SERIE 007

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8		
	007183	EA505-05D	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	

SERIE 008

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8		
	008182	008182FD	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	
008183	008182FD	EA205-06D	073.520-7	019.308-0	EA205-03	056.689-7	061.877-1	031.105-2	066.999-5	90

SERIE W 2.000

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8	9	
	EW 205-00	EA 205-07	EA 205-31	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	

SERIE W 4.000

Código del Embrague	Código de los Componentes									Par (kgf)
	1	2	3	4	5	6	7	8	9	
	EW 405-00	EA 205-07	EA 205-02	EA 205-01	EA 205-03	EA 205-11	EA 205-04	EA 205-05	EA 205-06	